

Santa Monica Filtration®

Installing new RAIN red cap



1. Clean with alcohol and apply thin coat of silicone.



4. Put rubber band around part.



2. Point small triangle towards end of pipe.



5. Check triangle and slot alignment; end is flush.



3. Put on pipe and line up slots.



6. After drying overnight, push on cap and turn right.